



ALUMINIUM WOOD PRIMER

DESCRIPTION

A PHENOLIC RESIN BASED PRIMER MODIFIED WITH TUNG OIL AND LINSEED OILS. FOR USE AS A HIGH QUALITY WOOD PRIMER IN COMBINATION WITH LITTLE GREENE OIL-BASED PAINTS. CAN SUBSTITUTE FOR TRADITIONAL LEAD-BASED WOOD PRIMERS WITHOUT THE ASSOCIATED TOXICITY ISSUES.

SURFACES

SOFTWOODS INCLUDING PRESERVATIVE TREATED AND NON-OILY HARDWOODS. SUITABLE FOR NATURALLY RESINOUS TIMBERS AND AS A KNOT SEALER. NOT RECOMMENDED WHERE TAR OIL (CREOSOTE) HAS BEEN USED.

PACK SIZES

1 LITRE
2.5 LITRE

COLOUR RANGE

PINK METALLIC

SPREADING RATE

UP TO 10 SQUARE METERS PER LITRE ON SMOOTH FLAT SURFACES.
TYPICALLY 8-9 SQUARE METRES PER LITRE ON UNCOATED
SOFTWOODS

DRYING RATE

NORMALLY TOUCH DRY IN 4-6 HOURS. CAN BE RECOATED OR
OVERCOATED AFTER OVERNIGHT DRYING

TECHNICAL INFORMATION

SHEEN LEVEL

EGGSHELL

SPECIFIC GRAVITY

1.09

SOLIDS BY VOLUME

55% APPROXIMATELY

DRY FILM THICKNESS

55-60 MICRONS PER COAT ON SMOOTH SURFACES

PREPARATION

SURFACES MUST BE CLEAN, DRY AND FREE FROM LOOSE AND FLAKING MATERIAL, DIRT, GREASE ETC. OILY HARDWOODS SHOULD BE THOROUGHLY WIPED OVER WITH WHITE SPIRIT BEFORE PRIMING.

1 of 2 pages

August 2009

ALL THE INFORMATION SUBMITTED ON THIS SHEET IS CORRECT TO THE BEST OF OUR KNOWLEDGE AND EXPERIENCE. THE LITTLE GREENE COMPANY RESERVES THE RIGHT TO MODIFY DATA AND SYSTEMS SHEETS AND PROCEDURES WITH REFERENCE TO USAGE AND APPLICATION WITHOUT FURTHER NOTICE. THE INFORMATION SUPPLIED DOES NOT ABSOLVE USERS FROM RESPONSIBILITY TO CARRY OUT THEIR OWN TESTS AND EXPERIMENTS, NOR DOES IT IMPLY ANY LEGALLY BINDING ASSURANCE OF CERTAIN PROPERTIES OR SUITABILITY FOR ANY SPECIFIC PURPOSES. CONDITIONS OF APPLICATION AND SERVICE MAY BE BEYOND OUR CONTROL, SO NO LIABILITY WHATSOEVER CAN BE ACCEPTED ON THE BASIS OF THE INFORMATION SUPPLIED HEREIN.



ALUMINIUM WOOD PRIMER

AREAS REQUIRING THE USE OF WOOD FILLER E.G. AFTER THE REMOVAL OF DECAYED WOOD OR WHERE CRACKS ARE PRESENT SHOULD BE PAINTED WITH LITTLE GREENE ALUMINIUM WOOD PRIMER BEFORE AND AFTER FILLING.

APPLICATION

STIR WELL BEFORE USE. BEST APPLIED BY BRUSH ALTHOUGH LARGER AREAS CAN BE COATED BY ROLLER. SOME SOFTWOODS MAY REQUIRE UP TO 5% THINNING WITH WHITE SPIRIT TO EASE APPLICATION. APPLY 1 OR 2 COATS AS REQUIRED FOLLOWED BY LITTLE GREENE OIL PRIMER UNDERCOAT AND OIL-BASED GLOSS OR EGGSHELL. WHERE THOSE ARE PALE COLOURS AN EXTRA COAT OF PRIMER UNDERCOAT MAY BE NECESSARY TO COMPLETELY COVER THE ALUMINIUM WOOD PRIMER.

CLEAN UP

EQUIPMENT SHOULD BE CLEANED WITH WHITE SPIRIT IMMEDIATELY AFTER USE.

PRECAUTIONS

ALWAYS READ THE CAN LABEL BEFORE USE. ENSURE MAXIMUM VENTILATION DURING APPLICATION AND DRYING. DO NOT APPLY BELOW 5°C – DRYING WILL BE SLOWER AT LOWER TEMPERATURES.